

# LIGHTING ACCESSORIES

SOCKETS (medium base) AND ADAPTERS

# ATRON

**CHROME &  
BRASS  
100 W MAX**



TRI-LIGHT SOCKET  
LA846



PUSH THROUGH SOCKET  
LA847



PULL CHAIN SOCKET  
LA848



PUSH THROUGH SOCKET  
LA972

**PHENOLIC  
100 W MAX**



2" BOTTOM TURN  
SWITCH  
LA958



PUSH THROUGH SOCKET  
LA942



TRI-LIGHT SOCKET  
LA943



PULL CHAIN SOCKET  
(brass chain)  
LA936



TURN KNOB SOCKET  
W/SCREW RING  
LA934

**PORCELAIN  
100 W MAX**



SOCKET  
1 1/2" (32mm) HICKEY  
LA938



KEYLESS  
SOCKET  
LA967



PORCELAIN  
SOCKET  
W/LEADS  
LA991



KEYLESS  
SOCKET  
LA999



SOCKET EXTENDER  
MED.-MED  
LA997